

CASEMENT GLASS REPLACEMENT INSTRUCTIONS

- 1) REMOVE SASH FROM UNIT.
- 2) USING A STANDARD SCREWDRIVER, REMOVE GLAZING BEADS. (INSERT SCREWDRIVER BETWEEN SASH AND BEAD – ROTATE TO REMOVE).
- 3) USING A UTILITY KNIFE, CUT GLAZING TAPE ON ALL SIDES.
- 4) CAREFULLY REMOVE GLASS.
- 5) INSTALL REPLACEMENT GLASS PANEL. (REMOVE GLAZING TAPE BACKER BEFORE INSERTING).
- 6) USING A MALLET, INSTALL GLAZING BEADS.
- 7) INSTALL SASH INTO MAINFRAME.

